

Rinnai

FLFVA5FLEX

Flexible Chimney Liner Kit Rinnai Royale IB35 Assembly & Installation Instructions

These components and the heater with which they are installed shall be installed in accordance with:

- Manufacturer's Appliance Installation Instructions
- Current AS/NZS 5601 Gas Installations
- Local Regulations and Municipal Building Codes

These components must be installed, serviced and removed by an Authorised Person!

Only the flue system components specified in this installation instruction must be used. Components not specified in this installation instruction, whether manufactured by rinnai or otherwise, are not compatible and "must not" be used!

FLUE KIT CONTENTS

- ① Chimney Plate
- ② Chimney Cowl
- ③ Flexible Chimney Liner (5 Metres)
- ④ Appliance Adaptor
- ⑤ Appliance Adaptor Handle
- ⑥ Bag of Fixing Materials:
 - Ⓐ Screws (x 6)
 - Ⓑ Rivets (x 2)

CONNECTING FLUE TO HEATER

Attach the appliance adaptor handle ⑤ to the front bottom of the appliance adaptor ④ using the pre-drilled hole and supplied rivet Ⓑ.


Engage the appliance adaptor ④ with the angled guide rails of the heater Ⓒ. Then using the appliance adaptor handle ⑤ pull the flue assembly fully forward and home.

Ensure that the appliance adaptor handle ⑤ is then securely fastened to the flue access plate of the heater Ⓓ.

For further information regarding this product contact Rinnai Australia.

1300 555 545

(Cost of a local call, higher from mobile or public phones)



Rinnai

FLFVA5FLEX

Flexible Chimney Liner Kit Rinnai Sapphire RIB2310 Assembly & Installation Instructions

These components and the heater with which they are installed shall be installed in accordance with:

- Manufacturer's Appliance Installation Instructions
- Current AS/NZS 5601 Gas Installations
- Local Regulations and Municipal Building Codes

These components must be installed, serviced and removed by an Authorised Person!

Only the flue system components specified in this installation instruction must be used. Components not specified in this installation instruction, whether manufactured by rinnai or otherwise, are not compatible and "must not" be used!

FLUE KIT CONTENTS

- ① Chimney Plate
- ② Chimney Cowl
- ③ Flexible Chimney Liner (5 Metres)
- ④ Guide Plate
- ⑤ Guide rails (x 2)
- ⑥ Bag of Fixing Materials:
 - Ⓐ Screws (x 6)
 - Ⓑ Rivets (x 2)
 - Ⓒ Small Screws (x 6)

Note: Transition Box **D** is provided with the heater engine or separately as part SAPFSSA.

CONNECTING FLUE TO HEATER

Attach the guide rails **⑤** to the heater using the pre-drilled holes and 4 short screws **Ⓒ**.

Align the guide plate **④** with the guide rails **⑤** and slide the flue assembly, forward until the front tab of the guide plate **④** is fully forward and home, against the rear of the flange at the top of the heater engine main body **E**.

Ensure that the guide plate is then securely fastened with two short screws **Ⓒ** to the flue access plate **F**.

For further information regarding this product contact Rinnai Australia.

1300 555 545

(Cost of a local call, higher from mobile or public phones)

