

# Adjusting the Thermostat

## STORAGE WATER HEATERS

- The hot water being delivered to your hot tap is generally a mixture of hot water from your storage tank and cold water to achieve the correct temperature (for example, 40°C).

The hotter the stored water (for example, it may be stored at temperatures up to 70° or 75°C), the more cold water you need to add to this to achieve the same temperature. Therefore, you are using less hot water to achieve the same temperature at the tap, which means that the same amount of stored hot water will last longer.